

Ascent-Descent Differences in Radiosonde Pressure and Temperature Measurements

Dale Hurst

Global Monitoring Division, NOAA Earth System Research Laboratory and Cooperative Institute for Research in Environmental Sciences, University of Colorado, Boulder




GRUAN ICM-5 De Bilt, The Netherlands



February 25 - March 1, 2013



Why do we want descent measurements?



Why do we want descent measurements by radiosondes?

To calculate this
from FPH data:

Water vapor mixing ratio

Relative Humidity

Need coincident
measurements of:

Ambient Pressure

Ambient Temperature


Why do we want controlled descent measurements?

NOAA FPH frost control is better at controlled descent rate of $5 \text{ m}\cdot\text{s}^{-1}$ than during free fall ($40\text{-}50 \text{ m}\cdot\text{s}^{-1}$)


Ascent-Descent measurements of Pressure and Temperature by radiosondes may agree better



Differences between Ascent and Descent Data




GRUAN ICM-5 De Bilt, The Netherlands



February 25 - March 1, 2013


Differences between Ascent and Descent Data: RS92 Pressure

Controlled Descent (“Turn”)
significantly reduces RS92
ascent-descent pressure differences




Differences between Ascent and Descent Data: RS92 Temperature

Controlled Descent (“Turn”)
does not reduce RS92
ascent-descent
temperature differences




Differences between Ascent and Descent Data: RS92 Geopot. Height

Controlled Descent (“Turn”)
significantly reduces RS92
ascent-descent
geopotential height differences




Differences between Ascent and Descent Data: Imet Pressure

Controlled Descent (“Turn”)
significantly reduces Imet
ascent-descent pressure differences




Differences between Ascent and Descent Data: IMET Temperature

Controlled Descent ("Turn")
does not reduce iMet
ascent-descent
temperature differences





Differences between Ascent and Descent Data: Imet Geopot. Height



Controlled Descent (“Turn”) significantly reduces iMet ascent-descent geopotential height differences





Ascent and Descent Pressure Differences



Ascent and Descent Temperature Differences



Ascent and Descent Geopot. Height Differences



Summary of Results

For both RS92 and Intermet radiosondes:

- Differences between ascent and descent pressure are significantly reduced by controlled descent
 - Differences between ascent and descent temperature are not reduced by controlled descent
 - Differences between ascent and descent geopotential height are significantly reduced by controlled descent
-
- Intermet Ascent-Descent differences for pressure and geopotential height are smaller than for the RS92
 - Ascent-Descent temperature differences are similar for the two radiosonde types

